



Dimension: 3.0" w x 0.75" h
Scotia: 0.49" w x 1" h

FSNO5

LAMINATE STAIR NOSE

Finishes the end of a step.

Used with floors 8-12mm in height.

Always check dimensions of existing stairs, discuss with end user and make sure to keep records. Ensure that alternations to sub tread and addition of nosing maintains existing stair dimensions or is to code

Surface: Wear resistant laminate
Core Material: Moisture resistant MDF

1

Install the flooring leaving a 2" gap from the end of the step for the stair nose installation.

2

Measure and trim to fit.

Adjust height of stair nose using the included shim. **Remove foam padding from floor where applicable.*

3

Apply a generous bead of construction adhesive along the underside of the stair nose and the scotia. **Wipe off excess immediately.**

4

Carefully place the stair nose against the front of the step.

Press down firmly over the entire stair nose.

Install scotia underneath the FSN using both contractor's adhesive & finishing nails.

**The scotia should be flush against the bottom of the stair nose.*

For added security, secure with finishing nails.